



MODALITÀ D'USO DEL NUOVO SCHERMO A MOLLA

- 1 Appenderlo al muro o al soffitto facendo attenzione che sia perfettamente in bolla e allineato al piano focale del proiettore.
- 2 Aprire il telo tirandolo verso il basso. All'apparire della scritta **"STOP"**, superarla di circa 10 cm; rilasciare quindi il telo accompagnandolo dolcemente. Dopo circa 10 cm si bloccherà automaticamente rimanendo aperto.
- 3 Questo schermo può essere bloccato ogni 13 cm, sempre tirandolo verso il basso per poi lasciarlo rientrare lentamente.
- 4 Per richiudere il telo, tiratelo sempre verso il basso di circa 10 cm, quindi rilasciatelo accompagnandolo nella fase di rientro. Questo movimento deve essere più veloce di quello che si effettua per bloccare il telo descritto al punto 2.



- 5 **ATTENZIONE:** lo schermo non deve essere mai aperto per più di 20 centimetri dopo la scritta **"STOP"**.
- 6 Nel caso oltrepassiate la scritta **"STOP"** di oltre 20 centimetri e lo schermo si inceppi, afferrate con due mani il telo, tiratelo con un colpo secco verso il basso e verso di Voi per poi rilasciarlo immediatamente.

Se dopo questa operazione lo schermo rimanesse comunque inceppato, rivolgetevi al Vostro punto vendita.

IN NESSUN CASO, PREVIA PERDITA DELLA GARANZIA, LEVARE IL TAPPO NERO DEL TELAIO PER EFFETTUARE RIPARAZIONI!



HOW TO USE THE NEW SPRING OPERATED SCREEN

- 1 Hang it on a wall or from the ceiling, making sure it is perfectly horizontal and in line with the projector's focal plane.
- 2 Open the screen by pulling downwards. After the writing **"STOP"** appears, continue for around 10 cm.; now release the screen accompanying it gently. After around 10 cm. it will automatically lock, remaining open.
- 3 This screen can be locked every 13 cm., always by pulling it downwards and then by letting it return slowly.
- 4 To close the screen, pull it downwards once again by around 10 cm. and then release it accompanying it as it returns. This movement must be faster than the one used to lock the screen described in point 2.



- 5 **ATTENTION:** Never open the screen by more than 20 centimetres after the writing **"STOP"**.
- 6 If you do go beyond the writing **"STOP"** by more than 20 centimetres and the screen jams, take hold of it with two hands, jerk it downwards sharply and towards yourself and let go immediately.

If the screen is still jammed after this operation, contact your stockist.

NEVER REMOVE THE BLACK FRAME PLUG TO MAKE REPAIRS AS THIS INVALIDATES THE GUARANTEE!