



ACCESSORY MC17



0 663293 113545

INFORMATION

REFERENCE : **MC17**

PACKAGING : **SLEEVE**

COLOUR : **BLACK**

SIZE (L x H x W > MM) : **235 x 156 x 80**

OUTER CARTON QUANTITY : **4**

INNER CARTON QUANTITY : **/**

WEIGHT (G) : **340**

CROSSBODY BAG

- Padded back pocket holds and protects Nintendo Switch™ 2, Nintendo Switch™ OLED Model, or Nintendo Switch™, without Joy-Cons™ attached. Front pocket safely stores Joy-Cons™, AC Adapter, HDMI Cable, Joy-Con™ Straps and 2 Game Card Case. Adjustable shoulder strap. Soft Cleaning Cloth.
- Game Card Case 2 pcs:
Each case holds 4 Game Card.
- Micro SD Card Case 2 pcs:
Each case holds 2 Micro SD Cards and fits in any section of Game Card Case. Dust free protection.



R.D.S. INDUSTRIES INC.

COMPATIBLE WITH

- | | |
|---|------------------------------|
| ● | Nintendo Switch 2 |
| ● | Nintendo Switch |
| ● | Nintendo Switch – OLED Model |
| ○ | Nintendo Switch Lite |