

MOOER

GREEN MILE
Overdrive Pedal

Owner's Manual

Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Power Supply

Please connect the designated AC adapter to an AC outlet of the correct voltage. Please be sure to use only an AC adapter which supplies 9V (±10%) DC, center minus. The maximum working voltage shall not exceed 12V, otherwise may be dangerous equipment damage, fire or other problems.

Unplug the AC power adapter when not using or during electrical storms.

Connections

Always turn off the power of this and all other equipment before connecting or disconnecting, this will help prevent malfunction and / or damage to other devices. Also make sure to disconnect all connection cables and the power cord before moving this unit.

Cleaning

Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Location

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- Direct sunlight
- Heat sources
- Magnetic fields
- Extreme temperature or humidity
- Excessive dusty or dirty location
- High humidity or moisture
- Strong vibrations or shocks

FCC certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Main Features

- 2 Working Modes: Warm/Hot
- Full metal shell
- Very small and compact design

- True bypass switch
- DC 9V adapter power supply

Effects Explanation

Warm: Reconstruct a warm tube drive tone and nice dynamic response of classic tube amplifier, it provides a natural, smooth, creamy overdrive sound.

Hot: More powerful output than Warm mode, mighty crunch tone.

Panel Instruction

The diagram shows the top panel of the Moorer Green Mile Overdrive Pedal. It features a central 'OVERDRIVE' knob, a 'MODE' switch, and two footswitches labeled 'Hot' and 'Warm'. There are two input jacks (INPUT and OUTPUT) and a DC IN jack. A 'LEVEL' knob and a 'TONE' knob are also present. The Moorer logo and 'GREEN MILE' branding are visible on the panel.

- 1. TRUE BYPASS Footswitch:** Push down the footswitch to toggle between on and bypass status.
- 2. ON/OFF LED:** Shows the on/off status of GREEN MILE, when the LED is lit the effect is engaged.
- 3. DC IN Power Jack:** For power supply, use a 9-volt DC regulated AC adapter (plug polarity is positive on the barrel and negative in the center).
- 4. INPUT Jack:** 1/4" mono audio jack, for connecting guitar.
- 5. OUTPUT Jack:** 1/4" mono audio jack, outputs the signal.
- 6. Mode Switch:** Switch between Warm mode and Hot mode.
- 7. LEVEL Knob:** Adjusts the level of the overdrive sound.
- 8. TONE Knob:** Adjusts the tone color of the overdrive sound.
- 9. OVERDRIVE Knob:** Adjusts the gain of the overdrive sound.

Specification

Effects Modes: 2 (Warm, Hot)

Input: 1/4" monaural jack (impedance: 500k Ohms)

Output: 1/4" monaural jack (impedance: 10k Ohms)

Power Requirements: AC adapter 9V DC (center minus plug), recommended to use Moorer Micro Power

Current Draw: 7 mA

Dimensions: 93.5mm (D) × 42mm (W) × 52mm (H)

Weight: 150g

Accessories: Owner's Manual

** Disclaimer: Any specification's update won't be amended in this manual.*